


# UT 8777 - UT 8777S



Pos.	Teil-Nr.:	Bezeichnung	Menge
1	19014300	Betriebsdrücker	1
2	19014301	Vorspannstift	1
3	19014302	Gehäuse	1
4	19014303	Ventilbuchse	1
5	19014304	O-Ring	1
6	19014305	Ventilstößel	1
7	19014306	O-Ring	1
8	19014307	Ventilfeder	1
a	19014303	Mengenregler	1
10	19014309	O-Ring	1
11	19014310	O-Ring	1
12	19014311	Ventilschraube	1
13	19014312	Kugellager	1
14	19014313	Rotordeckel	1
15	19014314	Justierstift (2)	2
16	19014315	Zylinder	1
17	19014316	Rotor	1

Pos.	Teil-Nr.:	Bezeichnung	Menge
18	19014317	Rotorblatt (4)	4
19	19014318	Hülse	1
20	19014319	Abdeckung	1
21	19014320	Rotordeckel	1
22	19014321	Kugellager	1
24	19014323	Spannmutter	1
25	19020102	2" Schleifteller	1
	19020101	1" Schleifteller	1
27	19014326	Deflektor	1
28	19014327	O-Ring	1
29	19014328	Luftanschluß	1
30	19014329	Gabelschlüssel	1
31	19014330	O-Ring	1
32	19014331	Muffe	1
33	19014332	Komb. Zu- und Abluftschlauch	1